

QUICK START GUIDE CANON 5D MARK II

FORMAT THE CARD

Turn ON the Camera

Press MENU → Go to SETUP → Format → Card 1 or Card 2 → Press SET → OK

SETTING UP YOUR CAMERA

1. Reset Camera Settings
Press MENU → Navigate to SETUP3 → Select Clear Settings → Clear all Camera Settings → OK
2. Movie Format
Press MENU → Navigate to SETUP2 → Select Live View/Movie func. set → Select Stills + Movie → OK → Select Movie Display → OK

Press MENU → Navigate to SETUP2 → Select Live View/Movie func. set → Movie rec. size → 1920x1080 @25fps
3. Video System
Press MENU → Navigate to SETUP2 → Select Video System → Select PAL
4. Image Quality
Press MENU → Navigate to Shoot1 → Quality → Set to RAW + L → Press SET
5. Set the Mode Dial to M (Manual)
6. Set the Shutter Speed to 1/50
7. Set the ISO / Gain
8. Set the Aperture
9. Set White Balance
10. Set the Focus